



# WARRANTY AND CARE INSTRUCTIONS

## LIFETIME WARRANTY

Beginning on the date of the original installation, Dust Free® warrants to the original purchaser that this filter will be free from defects in materials and workmanship under normal use and service for the life of the filter. Provided that the filter is left installed at its original location, and proof of purchase to the original owner is provided. If necessary, Dust Free® will repair or exchange at their option, for the original purchaser, free of charge, F.O.B. factory, any unit which is defective in material or workmanship.

## SATISFACTION GUARANTEED

Dust Free® is confident that you will be pleased with the performance of the filter. So much so, we offer a 90-day money back guarantee.

## GENERAL CONDITIONS

This warranty shall not apply to any equipment that has been tampered with or altered in any way, or that has been subject to abuse, misuse, negligence, unusual operating conditions, accident, careless handling, improper installation, repairs by anyone outside of Dust Free®, or that has the serial numbers altered, effaced or removed. Warranty applies only to filters installed in North America.

## WARRANTY SERVICE

To obtain repairs and/or replacement parts under the terms of the Warranty, contact Dust Free® (972-635-9564) for a return authorization number. Then pack the unit carefully and ship, with the charges prepaid plus evidence of Consumer purchase date, to Dust Free®, 1112 Industrial Drive, Royse City, Texas 75189.

## FILTRATION AREA

Manufacturer recommends: 1 sq. ft. of filter surface area per ton a/c.



## CLEANING INSTRUCTIONS (Clean filter every 30-60 days.)

Prior to washing: Vacuum surface area to remove large dust and lint particles.

1. Lay the filter flat and spray it with a cleaning detergent on one side and then the other until the filter is soaked with the detergent. The amount of detergent required will be dependent upon the amount and type of air pollutants held in the filter.
2. Next, lay the filter with the dirtiest side down and flush the detergent from the filter using a garden hose with a nozzle set at the high pressure setting. A 1" or 2" object should be placed under one side of the filter frame to allow room for the water to escape. Turn the filter over and repeat the same procedure.
3. Perform steps 1 and 2 until the filter is clean. If the filter is extremely soiled, it may be more convenient to use a car wash facility to remove all imbedded dirt from the filter. Always lay the filter flat when using a high pressure water hose for cleaning.
4. Shake the excess water out of the filter and allow to drip dry to the extent that it can be carried without dripping water.

**IMPORTANT:** Your filter should be cleaned regularly to maintain maximum air flow in the system. DO NOT exceed water temperature of 200° Fahrenheit, as this may damage the filtering material. DO NOT use oil sprays or any other chemical sprays on the filter as this will dramatically reduce the "static-electric" effect. DO NOT wash in a dishwasher.

### SPECIAL NOTE

In some HVAC systems the pull tab is inaccessible when installed according to the air flow label. For these systems simply flip the filter over so the pull tab is accessible. Filter efficiency is not affected by reversing the air flow from what is indicated on the filter. In this reversed position be sure to wash the filter opposite to the direction indicated by the wash arrow.

### KEEP FOR YOUR RECORDS

FILTER MODEL AND SIZE

INSTALLATION DATE

SERIAL NUMBER

INSTALLER'S NAME

INSTALLER'S PHONE NUMBER

Your filter may be a deduction...

### Prescription for health care product.

PATIENT NAME

PATIENT NAME

CITY, STATE, ZIP

Your doctor has prescribed the use of an electrostatic air filter to aid in the relief of your health problem. Please keep a copy of this form with your records for insurance or allowed tax deductions.

PHYSICIAN NAME

ADDRESS

CITY, STATE, ZIP

PHYSICIAN'S SIGNATURE

### FILTER CLEANING LOG

Record the date you last cleaned the filter, to remind you of the next cleaning date.